CALIBURN

User Manual

©2025 By SHENZHEN

UWELL TECHNOLOGY CO., LTD.

All Rights Reserved

MIN CE IX CE IX

Illustration

- 3. Airflow adjustment valve
- 1. Cartridge 2. Device
- 4. LED light 5. Filler plug
- 6. TYPE-C charging port



Quick Guide

UWELL Take the cartridge off the device. CALIBURN G4 MINI Pod System then remove the insulating film

> from the bottom. 2. Open the filler plug to fill the cartridge with e-liquid, insert the cartridge back into the device. then wait for 10 minutes after its first filling.

- Specifications Materials: PCTG_PC
- Dimensions: 24 1mmx14mmx112 7mm
- Net Weight: 46 g
- Side E-liquid Capacity: 3 ml
- . Maximum Output Power: 35 W · Cartridge Specifications:
- FeCrAl Meshed 0.6Ω Cartridge · Battery Capacity: 1100 mAh

Instructions

device.

1. Cartridge Filling from the Side and Replacement a. Take the cartridge off the device

for the first filling and remove the

Put the filler plug back after filling.

d. Insert the cartridge into the

e. For the cartridge replacement,

please remove the used cartridge

from the device and insert a new

cartridge before use. b. Open the filler plug for filling.

insulating film on the bottom of the

when the e-liquid is under the MIN level.

2. Airflow adjustment

adjustment valve.



Take a draw to vape and during vaping, the corresponding battery level light gradually brightens, and performs a gradient color rotation when reaching its maximum brightness.

green when the battery level is above 60%, displays blue when the 60%, and displays red when the battery level is below 30%.

Attention:

- a. Insert the nozzle of the e-liquid bottle into the filling port until to the bottom and then fill it with e-liquid.
- b. Please put the filler plug back as soon as the filling is done, and make sure it is properly sealed to prevent e-liquid leakage. c. Let the new cartridge sit for 10
- minutes after the first filling to avoid coil burning. d. Please make a timely refilling

Adjust the airflow with the airflow



3. Vaping

4. Battery level indication During vaping, the LED light displays battery level is between 30% and

5. Charging

charging cable, the indicator light is

illuminated to indicate charging; the

flashing red light, flashing blue light

and flashing green light indicate low

battery level, medium battery level,

on continuously after charging is

6. Protection and Indication

the device stops outputting.

b. Low voltage protection: When

the battery power is insufficient

10 times and the device stops

c. Overtime protection: When the

vaping exceeds 8 seconds, the

d. Open-circuit protection: When

an open-circuit occurs under a no

situation, there is no output during

vaping and the blue light flashes 3

cartridge is inserted, the LED light

will light up directly and gradually

turn off after 200ms; when the

cartridge is pulled out, the blue

light flashes twice.

e. Prompt for cartridge insertion

and extraction: When the

device stops outputting.

cartridge or disconnection

green light flashes 5 times and the

during output, the red light flashes

a. Short-circuit protection: When a

short-circuit occurs, the red light

flashes 3 times during vaping and

and sufficient battery level,

completed.

outputting.

Warm Tips When connecting the device to a 1. Please charge with the certified power source through a TYPE-C high-quality power adaptor

> (5V/1A) and Type-C cable. 2. Please remove the cartridge from the device and store it separately when you travel by air, for the air pressure change may cause

leakage. 3. Avoid high temperature, low

respectively, and the green light stays temperature, flammables, explosives, water, and humid environment during the use or storage of the product. Please do

charge the device at least once a month to prolong its service life.

WARNING The new FDA regulations apply to the sales and distribution of all

not keep the product with hard

objects to avoid damage. Please

E-cig products. Do not give away free samples. 2. It is prohibited to sell all types of

E-cig products to people under the age of 21. 3. It is prohibited to sell all types of E-cig products in vending machines except those specified by laws and

regulations. 4. It is prohibited to introduce products with "light", "low", "mild", or other similar descriptions in labels or

advertisements into interstate trade.

and women during breastfeeding

hypertension, diabetes, depression,

and asthma. Keep the product out

or patients with heart disease.

of the reach of children.

non-smokers, and animals

Please keep your package and the 5. It is strictly forbidden to be used by warranty card young children, pregnant women,

Attention:

on the page

within seconds.

Warranty Period 180 days from the purchasing date.

6. Please do not drink it.

substance.

7. It may contain nicotine, which is

product may cause intoxication.

and explosives when using or

Do not disassemble the product.

responsible for any product

by the improper operation.

11. Please consult your local vape

shop or contact us through

help using the product.

· Visit UWELL's official website

the SUPPORT navigation bar.

. Or you can enter the 16-bit

. Please scan the QR code on the

www.mvuwell.com to verify under

verify. The result will be displayed

anti-counterfeit code on the surface

box, and the result will be displayed

of the user manual into the input

Product Verification

damage or personal injury caused

service@myuwell.com if you need

charging to avoid hazards.

The company won't be

9. Please keep away from flammables

Device and atomizer only. Coil and known to be a highly addictive pod are excluded.

8. Swallowing or skin contact with this Warranty Service Excluded

Warranty Parts

Conditions 1. Expiration of warranty period.

2. Damage caused by failure to use, maintain and keep the product according to the requirements of the product instructions.

3. Damage caused by maintenance service personnel non-authorized by UWELL. 4. Damage caused by using inferior accessories of other brands.

5. Damage caused by the force

Warranty Service Guide

majeure.

1. You can ask the shop you purchased your vaping device for

the warranty service. 2. You can visit www.mvuwell.com

and ask for warranty service under package with your phone camera to the SUPPORT navigation bar. 3. You can contact us through

service@myuwell.com if you have any questions.

information.

Please use your phone camera to scan the QR code for further

